

## **Glitter Paint**

## Wedding Card Boxes

**ESTIMATED PROJECT TIME:** 1.5 Hours **CHALLENGE LEVEL:** Easy

#### **TOOLS & SUPPLIES:**

- · Specialty Glitter in Silver
- Plain Craft Boxes
- Craft Glue

- Ribbon
- Gloves
- Drop Cloth

It's easy as 1-2-3 to give plain craft boxes a little pizzazz with Rust-Oleum's Specialty Glitter paint. Cut openings and mount them together for a unique, DIY wedding card box.

- Out a large hole in the largest box and a small slit opening in the medium size box for the cards.
- Over a drop cloth, apply Specialty Glitter in Silver on the box tops and bottoms, covering every surface.
- Apply 3 or more light coats. For best results, apply multiple light coats instead of one heavy coat. Let each coat dry for a few minutes before adding the next.
- A Let the glitter dry for approximately 1 hour.
- Assemble the boxes, stacking one on top of the other. Secure with glue and ribbon.



## **Chalkboard Paint**

**BBQ** Menu

**ESTIMATED PROJECT TIME:** 2 Hours **CHALLENGE LEVEL:** Easy

#### **TOOLS & SUPPLIES:**

- A Picture Frame
- Old Sheets or Drop Cloth
- Foam roller, 1/4" to 3/8" Nap
- Chalkboard Brush-On
- Roller or Synthetic Brush

Let your guests know what's on the menu! This DIY chalkboard menu board is easy with a little Chalkboard paint and a picture frame.

- Find a spot outdoors and cover nearby items with drop cloths to protect them from paint splatters.
- 2 Take the glass out of the frame and clean the inside and outside of the glass, using a lint free cloth.
- (3) Using a foam roller, apply the Specialty Chalkboard Brush-On Paint on the outside of the glass. Avoid excessive brushing or rolling. Use light, even stokes to ensure an even and smooth finish.
- The chalkboard finish is ready to be used after 3 days. Before writing, condition the surface by rubbing the side of a piece of chalk over entire area and erase.
- **6** After the chalkboard is dry, display your menu for friends and family to admire



# 2X Ultra Cover & Decorative Paint Pens

Decorative Watering Can

**ESTIMATED PROJECT TIME:** 2 Hours **CHALLENGE LEVEL:** Easy

### **TOOLS & SUPPLIES:**

- · Hot Glue Gun And Glue
- New Or Used Watering Can
- Fake Flowers

- Decorative Paint Pens
- 2X Ultra Cover Satin 2X
- Ultra Cover Primer Spray

Let your guests know what's on the menu! This DIY chalkboard menu board is easy with a little Chalkboard paint and a picture frame.

- Prime your watering can with Rust-Oleum® Painter's® Touch Ultra Cover 2X Primer and allow to fully dry.
- Apply 2 light coats of Rust-Oleum® Painter's® Touch Ultra Cover 2X Satin Spray in the color of your choice.
- Hot glue flowers into the inset of the watering can.
- With an American Accents® Decorative Paint Pen, creatively draw 3 simple hearts.



## **Chalked Paint**

## Specialty Finish Planter

**ESTIMATED PROJECT TIME:** 1 Hours **CHALLENGE LEVEL:** Easy

### **TOOLS & SUPPLIES:**

- Chalked Paint
- Planter
- Succulents
- Pebbles
- Soil

- Sanding Block: Fine Grit
- Hammer
- Tack cloth
- Latex Gloves

This DIY succulent planter will brighten up any room. Here's how we made it in just a few easy steps:

- Always work in a well-ventilated area and use a drop cloth to protect your workspace from overspray. If your wooden planter has any handles, you should remove them prior to starting your project.
- When looking over your planter, lightly scuff the sides of your planter until you have a smooth finish. Once sanded, wipe off excess sawdust with a tack cloth.
- Set your planter on your drop cloth. Then, shake your can of Chalked Ultra Matte Spray for one minute after the mixing ball starts to rattle. Hold the can 10-12" away from the wooden planter and spray in a sweeping motion. Apply 2-3 light coats, allowing a few minutes in between each coat. Then, set the wooden planter aside to dry.
- A Follow the same painting procedure to paint the handles. Ones painted set aside to dry.
- To protect your wooden planter's finish, simply apply Chalked Protective Clear Coat. Shake the can for one minute after the mixing ball starts to rattle. Then, spray the can 10-12" away from your wooden planter. Be careful not to overspray.
- 6 Once the planter and handles are dry you can re-attach the handles by nailing them into the planter.
- Once everything is dry and ready to go, gather your succulents, dirt and pebbles. Then, place your succulents in the planter and cover the remaining space with dirt. Once covered, sprinkle pebbles over the dirt to give it a clean, trendy look.



# Weathered Wood Accelerator & Testors Craft Paints

Farmhouse Wood Sign

**ESTIMATED PROJECT TIME:** 2 Hours **CHALLENGE LEVEL:** Easy

#### **TOOLS & SUPPLIES:**

- Weathered Wood Accelerator
- Testors Acrylic Craft Paint
- Untreated Wood Plank
- Foam Brush

Gloves

- Painter's Tape
- Cosmetic Sponge
- Transfer Tape
- Vinyl Stencil

Weathered Wood Accelerator and Testors Craft paints will give you the farmhouse look you want on this DIY project. Create a wood sign for your home décor or give it as a gift.

- Prepare bare wood by sanding in the direction of the grain with a fine grit sandpaper. Remove any dust with a tack cloth, or lint-free rag. Stir the Wood Accelerator thoroughly before and occasionally during use.
- Apply the Wood Accelerator liberally to the entire project with a bristle or foam brush. Do not wipe away excess. Allow Weathered Wood Accelerator to sit on the wood for 30 minutes to hour for the final effect. To darken, a second coat may be applied after 1 hour.
- Once completely dry, apply vinyl stencil using the transfer tape. Peel paper backing from transfer tape and adhere adhesive side on top of vinyl stencil. The transfer tape is used to pick up the design and move it perfectly to the wood. Smooth out bumps and air bubbles and slowly peel adhesive portion (transfer tape) from one corner to the next, across the entire board, making sure vinyl stencil stays in place. Once transfer tape is removed, your vinyl stencil will be ready to paint! (Tip: Use painters tape to cover any open space that you do not want paint on while painting your stencil).
- Apply Testors Craft Acrylic paint in black and white with a foam brush or foam sponge, Remember to use a tiny amount of paint!
- A protective finish can be applied after 2 hours. We recommend using Rust-Oleum Matte Clear Enamel Spray to seal your finished sign.

TIP: For a lighter effect, apply product and wipe away immediately or lightly sand the finish with fine grit sandpaper once it is dry. To darken, a second coat can be applied after 1 hour.



# Varathane Fast Dry

## Wine Rack Masterpiece

ESTIMATED PROJECT TIME: 2 Days
CHALLENGE LEVEL: Advanced

#### **TOOLS & SUPPLIES:**

- Varathane Wood Stain
- Varathane Polyurethane
- (3) 2" x 4", 8' each
- 2" Circular Drill Bit
- (22) 2" Wood Screws
- Lint Free Rag

- Gloves
- Synthetic Bristle Brush
- Sandpaper: grits 120, 180, 220
- Tack cloth
- Heavy Duty Grip Hanger
- Set-up a workspace in a well ventilated area (such as a garage).
- 2 Cut each 2 x 4 into 32" pieces
- Using one 2 X 4 measure out the four spaces for the circular drill bit. Starting at the top measure 4 to 4.5 inch intervals. This is your preference; divide the four holes equally at either 4" intervals or 4.5" intervals. Once you have marked and cut out one of the boards, line up the remaining three boards and drill each 2 X 4 to match the original board.
- From the remainder of the 2 x 4's cut 4 pieces to 13.5" in length. These will be used for the rear
- 5 Line up the 2 X 4's that have been predrilled with the circular drill.
- 6 Attach the rear horizontal bars pointed downward and mount them just above the entry holes on the backside.
- Sand the entire surface lightly progressing from 120 grit, to 180 grit, finishing with 220 grit. Always sand in the direction of the grain.
- Remove sanding dust between each step by lightly dragging the tack cloth across the surface.
- Using a clean, lint free rag flood the entire surface with wood stain. More is better than less.
- Let the wood stain sit for 2-3 minutes, then wipe off any excess, using a clean rag, wiping in the direction of the grain. Ensure all excess stain is removed from the surface.
- 11 Let dry overnight.
- Apply Polyurethane with a high quality synthetic bristle paint brush.
- 13 Allow to dry 2-4 hours.
- Attach heavy-duty grip hanger to the back of the wine rack to hang.